

REC type Function

1. Move the **MODE** toggle to **REC type** and press down to select.
2. The following will show up the **LCD Display**.



(Fine REC)	Fine Record, .WAV file format, the best quality sound but creates much bigger
(Long REC)	Long time record, .act file format, average quality sound.
(Fine VOR)	High quality voice control recording, .WAV format. In this mode the MP3 will not record anything if there is no sound around. Recording is performed in .WAV file format for the best quality sound.
(Long VOR)	Same as above, but a .ACT is created.

VOICE RECORD PLAYBACK FEATURE

How to PLAY voice recorded files on the MP3 player

1. Turn on unit.
2. The **OPTION MENU** will show up in the LCD DISPLAY



3. Move the **MODE** toggle until the **RPL** icon is selected.
4. Press the **MODE** toggle button down.
5. Press the **PLAY/PAUSE** button to play voice recording.
6. Press and **hold** the MODE toggle down to exit the playback feature.

Refer to **MUSIC FEATURES** for pause, skip, fast forward, rewind, and file deletion features in voice record playback mode.

SYSTEM FEATURES

How to configure the unit for various options

1. Turn on unit.
2. The **OPTION MENU** will show up in the LCD DISPLAY



3. Move the **MODE** toggle until the **SYS** icon is selected and press MODE toggle button down.

4. The following will show up the **LCD Display**.



5. Press and **hold** the **MODE** toggle button down to exit.

System Function Overview

(Record Time)	Set recorded files date and time
(Back Light)	Set backlight timing
(Back Light Mode)	Set backlight color
(Language)	Set the language
(Power off)	Set auto-power off time
(Replay Mode)	Set the Replay mode
(Contrast)	Set LCD Contrast
(Online Mode)	Set removable disk
(Memory Info)	Flash memory capacity
(Firmware Version)	Display date of current firmware version
(Firmware Update)	Use setting for firmware update
(Exit)	Exit the submenu

Telephone Book Features

How to create contact information

1. Insert CD into computer.
2. Go to directory D:\MP3 Aptools (H)\telbook
3. Copy and paste the **tel_en** file to the desktop.
4. Double Click on the **tel_en** file **on the desktop**.
5. Enter contact information and click **Add** button. Input all contacts, then click the **Save** button.
6. A new file called **TelBook** will be created **on the desktop**.

How to import contacts to unit

1. Plug unit into computer, open E: drive, copy **TelBook** file from desktop and paste on to unit.
2. Remove unit from computer and turn unit on.
3. Move **MODE** toggle to **TEL** icon and press toggle down.
4. Move **MODE** toggle to **Import Tel** icon and press toggle down (*confirm, yes*)
5. Move **MODE** toggle to **YES** and press toggle down.

How to view contacts on unit

1. Move **MODE** toggle to **TEL** icon, press toggle down.
2. Move **MODE** toggle to **Browse Tel** and press toggle down.
3. Press **PLAY/PAUSE** button to select contact.
4. Move **MODE** toggle to view contact information.



Digital MP3 Player – Voice Recorder
USB Memory Stick

Getting Started

How to put music or data files into the unit.

1. Plug the unit into the USB port of your computer.
2. The computer should automatically recognize the device as a Removable Drive.
3. The following screen will pop up*:



4. Click on the *Open folder to view files*.
5. A new window will open up that contains the files currently on the unit.
6. **Drag** or **copy/paste** .mp3

files, .wma files, .wav files or data files into the MP3 player folder.

* If the screen does popup, then double click on the **My Computer icon** on the desktop. The following screen should popup:



Double click on the **Removable Disk** icon to view the files currently on the unit. Windows 98 users will need to use the accompanying disk to install the MP3 Player driver.

Familiarize Yourself With The Unit

